


# Power and Switch Location



GRAML


Max Watt Strip Heater with lights

Note: View is from the top.



**Power:** Numbers indicate potential power locations.

- Locations 9 & 10 are on the bottom of the warmer and are intended to be used in conjunction with the optional legs supplied by Hatco. Note: maximum of 3 circuits down the leg.



**Switch:** Letters indicate the potential control box locations. Warmers with attached switch boxes are limited to power locations 3A and 4A. Remote switches allow you to utilize any of the power locations.

Note: Remote controls are available and recommended.